



WAVE PROCESSOR 9335

Recorders 



Display, Convert, Calculate, and Print Waveforms with a PC



MEMORY HiCORDER 8855

Use Windows application software to display, convert, calculate and print large volumes of waveform data on a PC

The WAVE PROCESSOR 9335 is application software for Windows that enables users to display, print, convert, and calculate on large volumes of waveform data that has been recorded and collected by instruments in the MEMORY HiCORDER Series. In addition to being able to handle data recorded by existing MEMORY HiCORDERs, the 9335 can also handle in excess of 1GB of waveform data recorded by the MEMORY HiCORDER 8855. This new PC application also includes functions for checking and analyzing measured results, such as conditional search, numeric calculations, and cursor measurement.



ISO 9001
JMI-0216



ISO 14001
JQA-E-90091




<http://www.hioki.co.jp/>

HIOKI company overview, new products, environmental considerations and other information are available on our website.

Check waveforms and measured results on a PC


Waveform Display Screen and X-Y Display Screen



The 9335 lets you load binary files from a MEMORY HiCORDER and then check the waveform or measured results on the Waveform Display Screen and the Numeric Display Screen. The 9335 also supports the memory recorder function X-Y display. The Waveform Display Screen and the X-Y Display Screen also can be split into graphs for each channel.

Trigger Time	CH1[V]:VOLTAGE1	CH2[V]:VOLTAGE2	CH3[V]:VOLTAGE3
-0d0h 0m0.006s	9.37000000	7.55000000	
-0d0h 0m0.005s	9.88000000	7.93000000	
-0d0h 0m0.004s	9.47000000	7.61000000	
-0d0h 0m0.003s	8.07000000	6.46000000	
-0d0h 0m0.002s	5.87000000	4.75000000	
-0d0h 0m0.001s	3.10000000	2.50000000	
0d0h 0m0.0s	0.02000000	0.06000000	
0d0h 0m0.001s	-3.07000000	-2.42000000	
0d0h 0m0.002s	-5.85000000	-4.61000000	
0d0h 0m0.003s	-8.10000000	-6.47000000	
0d0h 0m0.004s	-9.58000000	-7.59000000	
0d0h 0m0.009s	-3.28000000	-2.53000000	
0d0h 0m0.01s	-0.18000000	-0.03000000	

The acquired data can be displayed as digital values on a timeline. Further, waveform images and digital values can be displayed simultaneously.



CH	Comment	Unit	Mode	Range	LFF	AAF	Coupling
CH1	VOLTAGE1	8950 analog	VOLTAGE	1V	OFF	---	DC
CH2	VOLTAGE2	8952 RMS	VOLTAGE	1V	OFF	---	DC
CH3	CURRENT	8953 H-RESO	VOLTAGE	1V	OFF	OFF	DC
CH4	TEMPERATURE	8953 H-RESO	VOLTAGE	1V	OFF	OFF	DC
CH5	FREQUENCY	8950 analog	VOLTAGE	1V	OFF	---	DC
CH6	MOTER	8952 RMS	VOLTAGE	1V	OFF	---	DC
CH7	INVERTER	8953 H-RESO	VOLTAGE	1V	OFF	OFF	DC
CH8	POWER	8953 H-RESO	VOLTA	1V	OFF	OFF	DC

Displays waveform information.

Waveform display screen

CH	A	B	B-A	Search
CH1[V]:VOLTAGE1	3.1V	-8.1V	-11.2V	20mV
CH2[V]:VOLTAGE2	2.5V	-6.4V	-8.9V	10mV
CH3[V]:CURRENT	1.88613V	-4.84187V	-6.74V	28.125mV
CH4[V]:TEMPERATURE	1.58563V	-4.01438V	-5.6V	45.625mV
CH5[V]:FREQUENCY	1.21V	-3.26V	-4.48V	-20mV
CH6[V]:MOTER	950mV	-2.39V	-3.3V	-10mV
CH7[V]:INVERTER	633.75mV	-1.6131V	-2.24687V	-10mV
CH8[V]:POWER	326.875mV	-786.25mV	-1.1V	-10mV
LA1:POWER	0	1		
LA2:MOTER	0	1		
LA3:INVERTER	0	1		
LA4:NOISE	0	1		
LA5:	0	0		

Trace cursor screen


Voltage cursor screen

Fast search by date, time, level, etc.


The 9335 allows you to jump to a position that satisfies certain conditions, and display the waveform and the measured value at that position. This function can also be used as a re-trigger function.

The following search criteria can also be specified:

- Date and time
- Maximum value
- Absolute maximum value
- Level up
- Window in
- Logic pattern (logic data only)
- Event mark
- Minimum value
- Absolute minimum value
- Level down
- Window out





Settings screen for search criteria (Top: Time search; bottom: Conditional search)




Measurement value at the search position (Cursor screen)


Printing and copying the waveform screen



When a waveform is displayed on the screen, you can copy that waveform to the Windows clipboard, or make a hardcopy of the waveform. You can also paste the waveform into text, as well as associate the waveform with whatever application you want to start when you open that waveform.



Statistical functions make data evaluation easy



Numeric calculation screen


Calculation setup screen

19 types of numerical calculations can be displayed for all the areas or a specific area only. In addition to effective value, maximum value, frequency, and other standard values, you can also calculate values for characteristics such as duty ratio and rise time.

Use the WAVE PROCESSOR to calculate the following: average value, maximum value, minimum value, maximum time, minimum time, peak-to-peak value, effective value, area, standard deviation, ON time, OFF time, number of times turned ON, frequency, period, duty ratio, pulse width, rise time, fall time, time to level


Converting data to CSV format

A displayed waveform can be converted into a CSV file, either in whole or in part. Cropping on/off, the cropping method, the time axis format, and other variables can be set. Converting to a CSV file allows you to use the data with spreadsheet software, etc.



Waveform display screen

A sample screen showing data that has been converted into CSV format and opened in Excel.



(Note) The use of MO discs, PC cards, and floppy disks and the availability of a LAN connection depend on the specifications of the recorder model in question.

Requires the LAN COMMUNICATOR 9333 to use LAN connection between PC and a MEMORY HiCORDER.

● Displaying and printing measurement results through a PC

The WAVE PROCESSOR 9335 is a PC application software that can be used to display and print waveform data recorded by a MEMORY HiCORDER, such as the 8855 or the 8841, 8842.

The application can load more than 1GB of waveform data recorded by the MEMORY HiCORDER 8855. (The maximum size of data files that can be handled in Windows 95/98/Me is 1GB, and may be less depending on the PC environment.)

Waveform data files can be transferred from a MEMORY HiCORDER to a PC via a PC card, MO disc, floppy disk, or LAN connection.

● Multiple display screens

In addition to a waveform display screen, the 9335 also provides a numeric value display screen and an X-Y display screen. Waveform data can also be displayed in multiple display screens simultaneously for comparison. The 9335 can also display a search screen, numeric calculation screen, cursor screen and other screens that can be used for detailed study and analysis.

● Support for creating reports with the print and copy functions

You can make detailed printouts of waveforms from your PC's printer, as well as select color or black and white printing, screen partitions, gauges, and other options. Make a hard copy of the waveform image that is displayed on the screen, or copy it to the clipboard. Edit the data using a word processor such as Word by simply pasting the image into documents.

● Converting data and opening it in spreadsheets

Widely used spreadsheet programs can be used to edit measurement data and create reports. The WAVE PROCESSOR 9335 allows you to convert acquired waveform data to CSV format.

WAVE PROCESSOR 9335

(Compatible with Windows 95/98/Me, NT 4.0/2000, and XP)

Specifications	
Compatible devices	Model 8861, 8860 (9335 Ver 1.10 or later, only single axis data for MEM, or REC function), 8855, 8842, 8841, 8840, 8835-01, 8835, 8826, 8825, 8808-01/8807-01, 8808-51/8807-51 (not for use harmonic analysis data), 8731-10, 8730-10, 8720, 8715-01, 8714-01
Supplied Media	One CD-R disc
Operating environment	Computers running Windows 95, 98, Me, Windows NT4.0, 2000 or XP, Pentium (133MHz) or better, at least 32MB of memory (Recommended: Pentium (200MHz) or better, at least 64MB of memory)
Display functions	<ul style="list-style-type: none"> ■Waveform Display: Displays image of loaded waveform data on screen ■X-Y display: Memory (.MEM) and power (.POW) only ■Digital Value Display: Displays waveform data as digital values, and allows images and digital values to be displayed simultaneously ■Cursor function: Allows you to display the time and potential differences between cursors A and B, the time and electrical potential between each cursor, and the absolute and relative times ■Scroll function ■Maximum number of channels: 32 analog channels, 32 logic channels ■Gauge display: Time gauge, voltage axis gauge ■Graphical input
File loading	<ul style="list-style-type: none"> ■Loading data format: Memory (.MEM, except for data stored in real time); recorder (.REC), effective value recorder (.RMS), power (.POW) ■Maximum loadable file size: Maximum size that can be stored by hardware (The maximum size that can be handled may be smaller in some PC environments.)
Data conversion functions	<ul style="list-style-type: none"> ■Target data: All data, data between cursors ■Data interval: Simple interval (number of samples can be specified) ■Data conversion: Converts analog waveform data into numeric values, converts logic data into binary ■Data conversion format: CSV format, tab delimited, space delimited (selectable when data is saved) ■Conversion channel: Can be selected when data is saved ■Batch conversion: Multiple files can be specified for batch conversion
Printing functions	<ul style="list-style-type: none"> ■Printing format: Can print with no partitions, 2 to 16 partitions, 2 to 16 columns, X-Y 1 to 4 partitions, gauges, channel comments ■Print preview ■Waveform screen hard copy ■Compatible printers: Any printer supported by the OS (color or black and white)
Parameter calculation functions	<ul style="list-style-type: none"> ■Target data: All data, data between cursors ■Calculation items: Average value, effective value, peak value, maximum value, time of maximum value, minimum value, time of minimum value, rise time, fall time, standard deviation, area, cycle, frequency, pulse width, duty ratio, ON time, OFF time, number of times turned ON
Other	<ul style="list-style-type: none"> ■Search functions: Event mark, date and time (absolute time, time relative to trigger), maximum, minimum, absolute maximum, absolute minimum, level up/down, window in/out ■Clipboard copy: Waveform screen, cursor value, digital value, file information ■Startup of other applications: Other applications can be launched by specifying run file

* Company names and product names that appear in this catalog are registered trademarks or trademarks of their respective owners.

HIOKI

HIOKI E. E. CORPORATION

HEAD OFFICE :

81 Koizumi, Ueda, Nagano, 386-1192, Japan
TEL +81-268-28-0562 / FAX +81-268-28-0568
E-mail: os-com@hioki.co.jp

HIOKI USA CORPORATION :

6 Corporate Drive, Cranbury, NJ 08512 USA
TEL +1-609-409-9109 / FAX +1-609-409-9108
E-mail: hioki@hiokiusa.com

Shanghai Representative Office :

1310 Shanghai Times Square Office
93 Huaihai Zhong Road
Shanghai, 200021, P.R.China
TEL +86-21-6391-0090, 0092
FAX +86-21-6391-0360
E-mail: info@hioki.cn

DISTRIBUTED BY

www.SignalTestInc.com <<http://www.SignalTestInc.com>>
1529 Santiago Ridge Way
San Diego, CA 92154 USA.
Sales@SignalTestInc.com

SIGNAL TEST
New & Used Test Equipment