## California Instruments Ls Series

## 3000-18000 VA

## 3-18 kVA Programmable AC Power Source / Analyzer

## 135–400 V

- Backward Compatible with L Series
   Function and bus compatible with the California
   Instruments L Series
- Three phase and Single phase modes Ideally suited for avionics and defense applications
- 3 kVA to 18 kVA Power Levels
   Match power source and cost to application requirements
- Transient Programming
   Test products for susceptibility to AC line disturbances
- Built-in Measurements
   Performs voltage, current, and power measurements
- Advanced Features
   Arbitrary waveform generation, harmonic analysis,
   GPIB interface are some of the available options
- Interface Standard USB & RS232C interface. Optional GPIB & LAN available
- CE Marked Safe, reliable, and consistent operation

#### Integrated System

The Ls Series is an improved version of the classic California Instruments L Series AC power sources. The Ls Series provides many basic AC source capabilities at an economical cost. Additional capabilities such as arbitrary waveform generation and harmonic analysis can be added as options.

The Ls Series can be ordered in either single phase (-1) or three phase (-3) configurations. Power levels range from 3 kVA to 6 kVA in a single chassis. Multiple chassis can be combined for power levels up to 18 kVA.

#### **Easy-To-Use Controls**

The Ls Series is completely microprocessor controlled and can be operated from simple front panel controls. A pair of analog controls located next to the backlit alphanumeric LCD display allows output voltage and frequency to be slewed up or down dynamically. For more advanced operations, a series of menus is provided using a dual line high contrast LCD display. An optional full keypad is available.



0-132 A

<b>%</b>	208	230	400
>		230	

ETHERNET USB GPIB R\$232

#### **Applications**

With precise output regulation and accuracy, high load drive current, multi or single phase mode and built-in measurement capabilities, Ls Series AC sources address many application areas of AC power testing. Additional features such as DO 160, MIL 704, Boeing, or Airbus test standards are available options that establishes the Ls Series as a solid choice for avionics or defense applications. All Ls Series AC sources are standard equipped with USB and RS232C remote control interfaces. GPIB and Ethernet (LAN) interfaces are optional.

#### Compatibility

Although the standard command language is SCPI, the Ls Series also offers functional and bus compatibility with the CI L Series AC power sources. Using the APE (Abbreviated Plain English) command syntax, the Ls Series can be used in existing test systems without having to modify program code. The APE language is part of the -GPIB option which includes a GPIB/ IEEE-488 interface.

Distributed by: www.SignalTestInc.com 1529 Santiago Ridge Way San Diego, CA 92154 USA. Sales@SignalTestInc.com



185

### Ls Series

#### **Transient Programming**

To simulate common line disturbance occurrences, the Ls Series offers a list of transient steps. These steps can be programmed from the front panel or downloaded over the interface using the Interface Instrument Control Software (GUI) program supplied. The GUI allows libraries of commonly used line disturbances to be created on disk for quick recall. Once downloaded, the transient program can be executed from the PC or from the front panel. AC transient generation allows the effect of rapid changes in voltage, frequency, phase angle and waveform shape on the unit under test to be analyzed. The Ls Series is available in either three or one phase output configurations and offers standard voltage ranges of 135 Vrms and 270 Vrms. A wide range of options can be added to customize the Ls Series to meet your specific application requirements.

#### **Voltage Range Options**

Output voltage range options are available to provide higher voltage outputs. In addition to the standard 135/270 V range pair, 156/312 Vrms (-HV option) or 200/400 Vrms (-EHV option) can be specified at the time of order. All voltage ranges are Line to Neutral. On three phase Ls Series models, maximum Line to Line voltages are 467 V (standard), 540 V (-HV option) and 692 V (-EHV option).

#### Phase Mode


The -MODE option provides automatic switching between three phase and single phase output modes. In single phase mode, all output current is routed to the Phase A output terminal. The -MODE option is available for 3 phase Ls configurations.

#### Waveform Generation


The standard Ls Series provides sine wave output capability. For more demanding test applications, the advanced option package (-ADV) adds the following waveform capabilities:

- Squarewave.
- Clipped Sinewave Simulates THD levels to test for harmonic distortion susceptibility.
- Harmonic and Arbitrary (User defined) waveforms.


Using the provided Windows GUI, defining harmonic waveforms is as easy as specifying the relative amplitude and phase angle for each of up to the 50th harmonic. The waveform data points are generated and downloaded by the ICS to the AC source through the standard RS232C, USB or optional LAN or GPIB bus and are retained in non-volatile memory. Up to 50 waveforms can be stored and named for easy recall.



Harmonic waveform, Fund., 3rd, 5th, 7th and 9th.



Three phase output mode.



Voltage sweep transient causes output voltage to change at a programmed rate.

#### Ls Series - Measurement and Analysis

The Ls Series measurement system is based on real-time digitization of the voltage and current waveforms using a 4K sample buffer. The digitized waveform data is processed by a Digital Signal Processor to extract conventional load values such as rms voltage, rms current, real and apparent power. With the addition of the advanced features option. (-ADV option), the same data can also be used to perform Fast Fourrier Transformation (FFT) to extract the harmonic amplitude and phase angle of 50 harmonics, or display acquired voltage and current waveforms.

#### **Standard Measurements**

The following standard measurements are available from the front panel or via the bus:

- Frequency and Phase
- Voltage (rms)
- Current(rms) and Peak Current
- Crest Factor
- Real Power and Apparent Power
- Power Factor

## Advanced Measurement Functions (-ADV option)

Power analysis of EUT load characteristics is available by adding the -ADV option. Harmonics up to the 50th harmonic (for fundamental frequencies up to 250 Hz) and total harmonic distortion of both voltage and current is provided as well.

Harmonic analysis data can be displayed on the front panel display or on the PC using the GUI program. The GUI can also be used to save and print harmonics data in tabular, bar graph or time domain formats.

The acquired voltage and current time-domain waveforms for each output phase can be displayed using the GUI program. Waveform displays on the PC. Available display modes include voltage and current combined, three phase voltage, three phase current and true power. The time-domain data is also available for transfer to a PC through the bus when using custom software.

#### **Diagnostics Capability**

The AC Source can perform a self test and report any errors. The self test will run until the first error is encountered and terminate. The response to the self test query command will either be the first error encountered or 0 if no error was found. (Self test passed).

#### Windows Graphical User Interface

A Windows compatible Instrument Control Software (GUI) offers a soft front panel interface for operation from a PC. The following functions are available through this GUI program:


- Steady state output control (all parameters).
- Create, run, save and print transient programs.
- Measure and log standard measurements.

#### With -ADV option:


- Generate and save harmonic waveforms.
- Generate and save arbitrary waveforms.
- Capture and display Voltage and Current waveforms.
- Measure, display, print and log harmonic voltage and current measurements.




Standard measurements for all phases.



Standard measurements for all phases.



Standard measurements for all phases.



# **Ls Series : Specifications**

Output				00 \/\ 45001 c			1500 \/\ 6	0001 c+ 1 nhac	v euuu //v 3	nhaco: 2000 V	
Maximum Power per phase	3000Ls: 1 ph	3000Ls: 1 phase: 3000 VA, 3 phase: 1000 VA; 4500Ls: 1 phase 4500 VA, 3 phase 1500 VA; 6000Ls: 1 phase 6000 VA, 3 phase: 2000 VA									
Power factor	0 to unity at	0 to unity at full output VA									
Voltage Ranges	Range	Range V Low V High VA Programming Resolution 100 mV									
	AC	0-135V 0-270V Load Regulation				< 0.1 % FS					
	Can IIV and	Line Regulation < 0.02 % for 10 % line change									
	See -HV and	See -HV and EHV options for alternative voltage range pairs.									
Programming Accuracy (25°C ±5°C		Voltage (rms): $\pm$ (0.05% + 0.25) V from 5.0 V to FS; Frequency: $\pm$ 0.025 45 Hz - 819.1 Hz, $\pm$ 0.7 % > 819.1 Hz; Phase: $\pm$ 1° 45-100 Hz, $\pm$ (1° + 1°/kHz) 100 Hz-1kHz									
Frequency Range	45 Hz - 1000	45 Hz - 1000 Hz (see -HF option for higher output frequencies) 17 - 45 Hz operation available at reduced voltages									
Frequency Resolution	0.01 Hz at <	0.01 Hz at < 81.9 Hz, 0.1 Hz at 82.0 to 819.1 Hz, 1 Hz2 at > 819 Hz									
Max RMS Current	V Range V	high V lov	w   < At Full Pov	ver Model	3000Ls-3 Ø 30	000Ls-1 Ø	4500Ls-3 Ø	4500Ls-1 Ø	6000Ls-3 Ø	6000Ls-1 Ø	
	-3 3 ø 7.4	1 A 14.8	A At FS Voltage	e > V Low	7.4 A 2	2.2 A	11.1 A	33.3 A	14.8 A	44.4 A	
	-1 1 ø 22	.2 A 44.4	A	V High	3.7 A 1	1.1 A	5.5 A	16.7 A	7.4 A	22.2 A	
	Note: Constant	power mode	on 3000Ls and 4500	OLs provides incre	ased current at reduce	d voltage; 60	00Ls provides i	maximum voltage	2.		
Current Limit	Programmab	le from 0 A	mps to maximu	m current for s	elected range						
Peak Current	3000Ls: 6 X	(Irms @ ful	l scale voltage);	4500Ls: 4 X (I	rms @ full scale v	oltage); 60	000Ls: 3 X (l	rms @ full sca	le voltage)		
Output Noise	100mV rms t	yp. (20 kHz	z to 1 MHz)	Harmonic Di	stortion < 1%	(at full sca	ale voltage, f	full resistive lo	ad)		
Isolation Voltage	300 V rms ou	utput to cha	assis	Output Relay	Push	button con	trolled and l	bus controlled	output relay		
<b>Input</b> Voltage					208-230 ± 10% \					(L-L, 3 Phase)	
-	Models 6000	)Ls, 12000l	Ls, 18000Ls: Sta	2400 option no	208-230 ± 10% V ) + 10% VAC (L-L t availble on 6000Ls, (208 6000Ls (208 38 A	., 3 Phase) 12000Ls, 1800 BV) Ini	450V L-L	: Consult fact s can be operated t @ 180	tory	 peak	
Voltage	Models 6000  Notes: 1. Input	ols, 12000l must be specif 3000ls	Ls, 18000Ls: Sta fied when ordering. 3000Ls (1Phas	ndard 208-230 2400 option no se) 4500Ls	+ 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208	3 Phase) 12000Ls, 1800  BV) Ini (Pe	450V L-L 00Ls. 3. 3000Ls rush Current	: Consult fact s can be operated t @ 180 @ 360	tory d from 1 phase AC 0-254 V: 50 A 0-440 V: 83 A	 peak	
Voltage	Models 6000  Notes: 1. Input to  Model  187 VLL	nust be specification of the s	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A	ndard 208-230 2400 option no se) 4500Ls 31 A	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A	3 Phase) 12000Ls, 1800  BV) Ini (Pe	450V L-L 00Ls. 3. 3000Ls rush Current er phase):	: Consult fact s can be operated t @ 180 @ 360	tory d from 1 phase AC 0-254 V: 50 A 0-440 V: 83 A	 peak	
Voltage  Line Current (rms per phase)	Models 6000  Notes: 1. Input to the second s	nust be specification of the s	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A	ndard 208-230 2400 option no se) 4500Ls 31 A	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A	3 Phase) 12000Ls, 1800  BV) Ini (Pe	450V L-L 00Ls. 3. 3000Ls rush Current er phase):	: Consult fact s can be operated t @ 180 @ 360	tory d from 1 phase AC 0-254 V: 50 A 0-440 V: 83 A	 peak	
Voltage  Line Current (rms per phase)  Efficiency	Models 6000  Notes: 1. Input to Model 187 VLL 360 VLL 75% typical	3000Ls   19 A   10 A	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A	ndard 208-230 2400 option no se) 4500Ls 31 A	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A	3 Phase) 12000Ls, 1800  BV) Ini (Pe	450V L-L 00Ls. 3. 3000Ls rush Current er phase):	: Consult fact s can be operated t @ 180 @ 360	tory d from 1 phase AC 0-254 V: 50 A 0-440 V: 83 A	 peak	
Voltage  Line Current (rms per phase)  Efficiency Power Factor  Hold-up Time	Models 6000  Notes: 1. Input I  Model  187 VLL  360 VLL  75% typical  0.6 typical	3000Ls   19 A   10 A	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A	ndard 208-230 2400 option no se) 4500Ls 31 A	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A	3 Phase) 12000Ls, 1800  BV) Ini (Pe	450V L-L 00Ls. 3. 3000Ls rush Current er phase):	: Consult fact s can be operated t @ 180 @ 360	tory d from 1 phase AC 0-254 V: 50 A 0-440 V: 83 A	 peak	
Voltage  Line Current (rms per phase)  Efficiency Power Factor  Hold-up Time  System	Models 6000  Notes: 1. Input to Model 187 VLL 360 VLL 75% typical 0.6 typical At least 10 n	3000Ls 3000Ls 3000Ls 19 A 10 A	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A n/a	ndard 208-230 2400 option no se) 4500Ls 31 A 16 A	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A	., 3 Phase) 12000Ls, 180    No.   Initial Phase   Initial Phas	450V L-L 00Ls. 3. 3000L rush Current er phase): ne Frequenc	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440	ory d from 1 phase AC 0-254 V: 50 A 0-440 V: 83 A 0 Hz	peak peak 	
Voltage  Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System  Storage	Models 6000  Notes: 1. Input i  Model  187 VLL  360 VLL  75% typical  0.6 typical  At least 10 n  Setup: 16 coi	must be specification of the s	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A n/a	ndard 208-23( 2400 option no se) 4500Ls 31 A 16 A	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A n/a	., 3 Phase) 12000Ls, 1800 BV) Ini (Pri Lir	450V L-L 00Ls. 3. 3000L rush Current er phase): ne Frequence	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440	ory d from 1 phase AC 0-254 V: 50 A 0-440 V: 83 A 0 Hz ent registers (.	peak peak APE mode)	
Voltage  Line Current (rms per phase)  Efficiency Power Factor  Hold-up Time  System  Storage  Trigger Input/Output	Models 6000  Notes: 1. Input i  Model  187 VLL  360 VLL  75% typical  0.6 typical  At least 10 n  Setup: 16 coi	must be specification of the s	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A n/a	ndard 208-23( 2400 option no se) 4500Ls 31 A 16 A	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 200 38 A n/a	., 3 Phase) 12000Ls, 1800 BV) Ini (Pri Lir	450V L-L 00Ls. 3. 3000L rush Current er phase): ne Frequence	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440	ory d from 1 phase AC 0-254 V: 50 A 0-440 V: 83 A 0 Hz ent registers (.	peak peak APE mode)	
Voltage  Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System  Storage	Models 6000  Notes: 1. Input to Model 187 VLL 360 VLL 75% typical 0.6 typical At least 10 n Setup: 16 co Input: Trigger	must be specification of the s	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A n/a	ndard 208-230 2400 option no se)	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 200 38 A n/a	., 3 Phase)	450V L-L 00Ls. 3. 3000L rush Current er phase): ne Frequence  (SCPI mode	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440 e) or 16 transie	ent registers (	peak peak APE mode)	
Voltage  Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System Storage Trigger Input/Output  Protection	Models 6000  Notes: 1. Input to Model 187 VLL 360 VLL 75% typical 0.6 typical At least 10 n Setup: 16 cool Input: Trigger Overload: Co	nust be specification of the s	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A n/a	ndard 208-23( 2400 option no se) 4500Ls 31 A 16 A  / Transient List nt steps - SMA	0 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A n/a :: 100 transient st	., 3 Phase) 12000Ls, 1800    Initial	450V L-L 00Ls. 3. 3000Ls rush Current er phase): ne Frequence (SCPI mode Output: S	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440 e) or 16 transie SMA Connector	ent registers (automatic s	peak peak  APE mode)  but  hutdown	
Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System Storage Trigger Input/Output  Protection Overload/Temp/Voltage Regulatory/RFI Suppresion	Models 6000  Notes: 1. Input to Model 187 VLL 360 VLL 75% typical 0.6 typical At least 10 n Setup: 16 cool Input: Trigger Overload: Co	nust be specification of the s	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A n/a	ndard 208-23( 2400 option no se) 4500Ls 31 A 16 A  / Transient List nt steps - SMA	1 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A n/a :: 100 transient st connector: 10K p	., 3 Phase) 12000Ls, 1800    Initial	450V L-L 00Ls. 3. 3000Ls rush Current er phase): ne Frequence (SCPI mode Output: S	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440 e) or 16 transie SMA Connector	ent registers (automatic s	peak peak  APE mode)  but  hutdown	
Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System Storage Trigger Input/Output  Protection Overload/Temp/Voltage Regulatory/RFI Suppresion Measurement Measurements	Models 6000  Notes: 1. Input to Model 187 VLL 360 VLL 75% typical 0.6 typical At least 10 n Setup: 16 cool Input: Trigger Overload: Co	nust be specification of the s	s, 18000Ls: Sta fied when ordering. 3000Ls (1Phas 32 A n/a rument setups a ments or transie rent or constant	ndard 208-23( 2400 option no se) 4500Ls 31 A 16 A  / Transient List nt steps - SMA	1 + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A n/a :: 100 transient st connector: 10K p	., 3 Phase) 12000Ls, 1800    Initial	450V L-L 00Ls. 3. 3000L rush Current er phase): ne Frequence  (SCPI mode Output: S ic Shutdowr	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440 e) or 16 transie SMA Connector n; Over voltage on: CISPR 11,	ent registers (automatic s	peak peak  APE mode)  but  hutdown	
Voltage  Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System Storage Trigger Input/Output  Protection Overload/Temp/Voltage	Models 6000  Notes: 1. Input it  Model  187 VLL  360 VLL  75% typical  0.6 typical  At least 10 n  Setup: 16 col  Input: Trigger  Overload: Col  IEC 1010, EN	must be specification of the s	s, 18000Ls: Sta fied when ordering.  3000Ls (1Phas 32 A n/a  rument setups // ments or transie rent or constant iN50082-2, CE, ncy 91 Hz 19.1 Hz	ndard 208-230 2400 option no se) 4500Ls 31 A 16 A  / Transient List nt steps - SMA voltage mode;	2) + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 200 38 A n/a	eps per list et: Automatents / RI	450V L-L 000Ls. 3. 3000Ls rush Current er phase): ne Frequence  (SCPI mode Output: \$  ic Shutdowr F Suppression AC rms) Re	cal Power  List Consult fact  Li	ent registers (, or: HCTTL outp	APE mode) but hutdown A	
Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System Storage Trigger Input/Output  Protection Overload/Temp/Voltage Regulatory/RFI Suppresion Measurement Measurements	Models 6000  Notes: 1. Input to Model 187 VLL 360 VLL  75% typical 0.6 typical At least 10 m  Setup: 16 cool Input: Trigger  Overload: Cool IEC 1010, EN  Parameter  Range  Accuracy* (±:	DLS, 12000I must be specification of the specificat	rument setups reent or constant in Stooms (Stanfied when ordering).  3000Ls (1Phas 32 A n/a	ndard 208-230 2400 option no se) 4500Ls 31 A 16 A  / Transient List nt steps - SMA  voltage mode; EMC, and safe  Phase 45-100 Hz 100-1000 Hz	2) + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A n/a  :: 100 transient st connector: 10K p  Over temperatur ty mark requirem  Voltage (AC) 0-400 V	eps per list bull-up / Current (,	450V L-L 00Ls. 3. 3000L: rush Current er phase): ne Frequence  (SCPI mode Output: S ic Shutdowr F Suppression AC rms) Re	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440 e) or 16 transie SMA Connector n; Over voltage on: CISPR 11, eal Power A	ent registers (, or: HCTTL outp	peak peak  APE mode)  Dut  hutdown  A  Power Factor  0.00-1.00	
Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System Storage Trigger Input/Output  Protection Overload/Temp/Voltage Regulatory/RFI Suppresion Measurement Measurements	Models 6000  Notes: 1. Input to Model  187 VLL  360 VLL  75% typical  0.6 typical  At least 10 n  Setup: 16 cool  Input: Trigger  Overload: Cool  IEC 1010, EN  Parameter  Range  Accuracy* (± 1 ø mode (-1)	DLS, 120001	s, 18000Ls: Sta fied when ordering.  3000Ls (1Phas 32 A n/a  rument setups // ments or transie rent or constant iN50082-2, CE, ncy 91 Hz 19.1 Hz	ndard 208-230 2400 option no se) 4500Ls 31 A 16 A  / Transient List nt steps - SMA  voltage mode; EMC, and safe  Phase 45-100 Hz 100-1000 Hz	t availble on 6000Ls,  6000Ls (@ 208  38 A  n/a  :: 100 transient st connector: 10K p  Over temperatur  ty mark requirem  Voltage (AC)	eps per list  Current (, 0-50 A	450V L-L 00Ls. 3. 3000L: rush Current er phase): ne Frequence  (SCPI mode Output: S ic Shutdowr F Suppression AC rms) Re 0-1	:: Consult fact s can be operated t @ 180 @ 360 y: 47-440 e) or 16 transie SMA Connecto n; Over voltage on: CISPR 11, feld by	ent registers (abover HCTTL output etc.) Apparent Power D-6 kVA	peak peak  APE mode)  Dut  hutdown  A  Power Factor  0.00-1.00	
Line Current (rms per phase)  Efficiency Power Factor Hold-up Time  System Storage Trigger Input/Output  Protection Overload/Temp/Voltage Regulatory/RFI Suppresion Measurement Measurements - Standard	Models 6000  Notes: 1. Input to Model 187 VLL 360 VLL  75% typical 0.6 typical At least 10 m  Setup: 16 cool Input: Trigger  Overload: Cool IEC 1010, EN  Parameter  Range  Accuracy* (±:	10 A	rument setups reent or constant in Stooms (Stanfied when ordering).  3000Ls (1Phas 32 A n/a	ndard 208-230 2400 option no se) 4500Ls 31 A 16 A  / Transient List nt steps - SMA  voltage mode; EMC, and safe  Phase 45-100 Hz 100-1000 Hz	2) + 10% VAC (L-L t availble on 6000Ls, 6000Ls (@ 208 38 A n/a  :: 100 transient st connector: 10K p  Over temperatur ty mark requirem  Voltage (AC) 0-400 V	eps per list  euch de la contraction de la contr	450V L-L 00Ls. 3. 3000L: rush Current er phase): ne Frequence  (SCPI mode Output: S ic Shutdowr F Suppression AC rms) Re 0-1	consult fact can be operated t @ 180 @ 360 y: 47-440 c) or 16 transie con: CISPR 11, c) over voltage on: CISPR 11, c) over voltage	ent registers (active Automatic s Group1, Class Group1, Class Apparent Power	peak peak  APE mode)  Dut  hutdown  A  Power Factor  0.00-1.00	

Note: Specifications are subject to change without notice. Specifications are warranted over an ambient temperature range of 25°± 5° C. Unless otherwise noted, specifications are per phase for a sinewave with a resistive load and apply after a 30 minute warm-up period. For three phase configurations, all specifications are for L-N. Phase angle specifications are valid under balanced load conditions only.

# **Ls Series : Specifications**

## 3000-18000 VA

Remote Control												
IEEE-488 Interface (option)	IFFF-488 (GPI	3) talker listener Subse	t· AH1 C0 [	OC1 DT1 I3 PP0 RI2 SH1	SR1 T6 IFFF-48	88 2 SCPI Synt	tax					
USB Interface & Ethernet		IEEE-488 (GPIB) talker listener. Subset: AH1, C0, DC1, DT1, L3, PP0, RL2, SH1, SR1, T6, IEEE-488.2 SCPI Syntax  Version: USB 1.1; Speed: 460 Kb/s maximum / Ethernet Interface (Optional): specify -LAN option. 10BaseT, 100BaseT, RJ45										
RS232C Interface	Bi-directional s	Bi-directional serial interface; 9-pin D-shell connector. Handshake: CTS, RTS. Databits: 7 w/ parity, 8 w/o parity. Stopbits: 2.  Baud rate: 9600 to 115200. Supplied with RS232C cable / Code and Format: SCPI; APE (option -GPIB)										
Physical Dimensions												
Dimensions (per chassis)	Height: 10.5"	Height: 10.5" (267 mm), Width: 19" (483 mm), Depth: 23.7" (602 mm) (depth includes rear panel connectors)										
Veight Veight		Chassis: Net: 193 lbs / 87.7 Kg, Shipping: 280 lbs / 127.3 Kg (for /2 or /3 model configurations multiply number of chassis)										
'ibration and Shock		Designed to meet NSTA project 1A transportation levels										
Air Intake/Exhaust		Forced air cooling, side air intake, rear exhaust										
emperature & Diagnostics		Temperature: Operating: 0 to 35° C, full power / Storage: -40 to +85° C; Diagnostics: Built-in self test available over bus (*TST)										
Rear Panel Connectors		<u> </u>		with safety cover. * IEEE-4	<u> </u>			, ,				
real ranel Connectors	connector (RS2	232 DB9 to DB9 cable s	supplied). *	Remote Inhibit (INH) and D terface connectors. * Auxilar	iscrete Fault Indic	ator (DFI). *						
Option -AX Specifications												
Option -AX	the 5 V for lam	p power. 26 Volt-Accu	racy: ± 2%.	5 Vac unregulated outputs. Current capacity: 3 ARMS. Fig. $\pm$ 5%. Current capacity: 5	requency:	ally used for se	ervo-synchro ex	citation, and				
Option -ADV Specifications												
Measurements - Harmonics	Parameter	Frequency Fundamer	ntal Harmon	ics Voltage		Current						
	Range	45-250 Hz / 0.09 -		Fundamental Harmonic	cs 2 - 50		al Harmonics 2	- 50				
	Accuracy* (±)	0.01% + 1 digit / 0.	5% + 1 dig	t 750 mV 0.3% + 750 n	nV+0.3% /1 kHz	0.5 A / 0.3%	5 A / 0.3% + 150 mA +0.3% /1 k					
	Resolution 0.01 Hz / 0.1 Hz 10 mV / 10 mV 10 mA / 10 mA											
	* Accuracy specifi	cations are in a percent of re	eading for singl	e unit in 3-phase mode.								
Vaveforms	Pre defined: Si	ne, Square, Clipped Use	er defined, 1	024 addressable data points	s; Storage: 50 use	r waveforms,	non-volatile m	emory				
ata Acquisition	Parameters: Vo	ltage, Current time dor	main, per ph	ase; Resolution: 4096 data ¡	points, 10.4 usec	(1ø) or 31.25	usec (3ø) sam	pling interval				
ption -HV Specifications												
oltage/Frequency Ranges		lt; High: 0-312 Volt / Fr 5 Hz - 5000 Hz	equency: Wi	th -HF option: 3000Ls, 4500	OLs, 6000Ls: 45 H.	z - 5000 Hz; 9	9000Ls, 12000	Ls, 13500Ls,				
Max RMS Current at Full Power				19.2 A, Low: 38.4 A; Note: 0 .s, and max voltage for 6000		nodes on 300	OLs and 4500L	s. Current				
Max RMS Current at FSVoltage				e: High 9.6 A, Low: 19.2 A; 4 v 12.8 A; 1 Phase: High: 19.		High: 4.8, Lov	v 9.6; 1 Phase:	High: 14.4 A				
Option -EHV Specifications												
oltage/Frequency Ranges	Voltage: Low:	0-200 Volt; High: 0-400	) Volt / Frequ	uency: With -HF option: 45 H	Hz - 5000 Hz							
Max RMS Current at Full Power		3 Phase: High: 5.0 A, Low 10.0 A; 1 Phase: High: 15.0 A, Low: 30.0 A; Note: Constant power modes on 3000Ls and 4500Ls. Current available at reduced voltage for 3000Ls, 4500Ls, and max voltage for 6000Ls										
Max RMS Current at FS Voltage				e: High 7.5 A, Low: 15.0 A; 4 v 10.0 A; 1 Phase: High: 15.		High: 3.8, Low	v 7.5; 1 Phase:	High: 11.3 A				
Option -HF Specifications												
Measurements:		Frequency	Phase	Voltage (AC)	Current (AC rms)	Real Power	Apparent Power	Power Factor				
< 2000 Hz: See standard Ls Specifications;	Range Accuracy* (±)	45 - 5000 Hz	< 2000 Hz > 2000 Hz	0-300 V < 1000 Hz / > 1000 Hz	0-50 A	0-5 kW	0-5 kVA	0.00-1.00				
> 2000 Hz: See table >	11 2 11	0.1% + 1 digit	0.5°	0.05% + 250 mV	0.5% + 150 mA	0.5% + 9 W	0.5% + 9 VA	0.03				
	3 ø mode (-3)		5°	0.1% + 0.1%/kHz +300MV	0.5% + 50 mA		0.5% + 3 VA	0.01				
	* Accurac specific		nd apply above	10 mV 100 counts. For multi-chassis conf > 50% of max. Frequency measure				0.01 ons are times				
250 m\/rmc typical (20 kHz to 1 MHz)												
50 mVrms typical (20 kHz to 1 MHz)		3000Ls 34500Ls, 6000Ls: Standard: -HV 45 Hz- 5000 Hz; - EHV: 45 Hz - 5000 Hz										
Output Noise	250 mVrms typ	oicai (20 kHz to 1 MHz)	250 mVrms typical (20 kHz to 1 MHz)									

© 2009 AMETEK Programmable Power All rights reserved. AMETEK Programmable Power is the trademark of AMETEK Inc., registered in the U.S. and other countries. Elgar, Sorensen, California Instruments, and Power Ten are trademarks of AMETEK Inc., registered in the U.S.

### Ls Series

Model <sup>1</sup>	Output <b>Power</b>	No of Out	Nom. Input Voltage <sup>2</sup>		
		-1	-3		
3000Ls	3 kVA	1	3	208-230 V	
3000Ls-400	3 kVA	1	3	400 V	
4500Ls	4.5 kVA	1	3	208-230 V	
4500Ls-400	4.5 kVA	1	3	400 V	
6000Ls	6 kVA	1	3	208-230 V	
9000Ls/2	9 kVA	1	3	208-230 V	
9000Ls/2-400	9 kVA	1	3	400 V	
12000Ls/2	12 kVA	1	3	208-230 V	
13500Ls/3	13.5 kVA	1	3	208-230 V	
13500Ls/3-400	13.5 kVA	1	3	400 V	
18000Ls/3	18 kVA	1	3	208-230 V	

Note 1: The /2 or /3 designation indicates number of chassis.

Note 2: All input voltage specifications are for Line to Line three phase, delta or wye. Model 3000Ls (208 V input) can be operated on 230 V L-N single phase if needed.

HF Table Model	Max. Freq.
3000Ls	5000 Hz
4500Ls	5000 Hz
6000Ls	5000 Hz
9000Ls/2	2000 Hz
12000Ls/2	2000 Hz
13500Ls/3	2000 Hz
18000Ls/3	2000 Hz

### Ordering Information

#### Model

Refer to table shown for model numbers and configurations. Specify number of output phases (-1 or -3) as part of model number, eg 4500Ls-1 or 4500Ls-3.

#### Supplied with

User / Programming Manual on CD-ROM, Software and RS232C serial cable.

#### Options

#### **Input Options**

400 ±10% Volt Line to Line AC input. -400[Not available on 6000Ls, 12000Ls and 18000Ls Models]

-480 480 ±10% (3 phase output only)

#### **Output Options**

Auxiliary outputs, 26 VAC, 5 VAC. -AX Limits upper frequency to 800 Hz.

156/312 V output range. -HV

-EHV 200/400 V output range.

-HF Extends upper frequency limit.

See HF table.

-LF Limits output frequency to 500 Hz.

#### **Keypad Options**

-KPD Upgraded keypad control panel.



#### **Cabinet Options**

-RMS Rackmount Slides. Recommended for rack mount applications.

C prefix Cabinet System. Installed and pre-wired in 19" cabinet.

#### **Controller Options**

RTCA/DO-160, Change 2, -160

EuroCAE-14D [Section 16, AC only]

-704F Mil-Std 704 rev A - F

-704 Mil-Std 704 rev D and E test firmware. [AC only]

[AC only]. Requires -ADV and use of Windows PC and included LxGui software. -AMD Airbus AMD24 Test

Airbus Directive 0100.1.8 tests.

-A350 Airbus Test Software

-ABD

-AIRB Airbus A380, A350 & AMD24 package

-ABL **Emulates Elgar SL Series** -B787 Boeing 787 Test Software

-ADV Advanced feature set. Adds arbitrary waveform generation and harmonic analysis of voltage and current.

-GPIB GPIB interface and APE programming language.

-LAN Ethernet Interface.

-MB Multi-box. Adds controller to auxiliary chassis of multi-chassis systems.

-MODE Add phase mode selection for 3 models

-L22 Locking Knobs.

-LKM Clock and Lock Master

-LKS Clock and Lock Auxiliary

Line Sync. -I NS -EXS External Sync.

#### Ontion Matrix

Option Watrix									
	HF	LF	HV	EHV	LKM	LKS	EXS	AX	
HF	-	х	0	0	х	х	0	х	
LF	х	-	0	0	0	0	0	0	
HV	0	0	-	х	0	0	0	0	
EHV	0	0	х	-	0	0	0	0	
LKM	х	0	0	0	-	х	0	0	
LKS	х	0	0	0	х	-	х	0	
EXS	0	0	0	0	0	х	-	0	
AX	Х	0	0	0	0	0	0	-	

Note 1: See ontion matrix

Note2: -LKS, -LNS and -EXS are mutually exclusive and with Ext Trig function.