





DIELECTRIC WITHSTAND

Model HT-10000P ac / dc is a 10,000V AC or 14000V DC Hipot Tester



Features

- AC output: up to 10,000 V.
- DC output: up to 14,000 V.
- Microcontroller Technology, one button test, easy to setup, LED's indicate test progress. Upon failure, buzzer sounds and testing is terminated.
- Output voltage, leakage current limit, voltage ramp-up time and test duration are controlled from the front panel.
- Voltage ramp, arc detection and test timer are defeatable.
- Separate arc detection circuitry.

- Ergonomically designed for safety, speed and efficiency.
- Designed for product development and laboratory use.
- Cables, manual and calibration certificate included.
- One year calibration cycle.
- One year warranty.

Distributed By:

Signal Test, Inc 1529 Santiago Ridge Way San Diego, CA 92154 Tel. 1-619-575-1577 USA www.SignalTestInc.com Sales@SignalTestInc.com



HT-10000P ac /dc > FAST









RELIABLE



Specifications

Voltage Test Type: AC & DC

0 - 10,000VAC & 0 - 14,000VDC Maximum Output Voltage: Maximum Leakage Current: AC: 0 - 8000V=10mA, 10000V=8mA DC: 0 - 10000V=5mA, 14000V=1mA

120 V *optional different line voltages available (100V, 110V, 220V, 230V, 240V) Input Voltage:

Frequency: 60 Hz

Fuse: 120/230 VAC 2 A Slow Blow Breakdown Detect: Independent High Frequency Circuit

Transformer Power: < 500 VAC

Leakage Current Detect: Independent Low Frequency Circuit

1 - 5 Seconds Ramp Time Range: Test Time Range: 1 - 60 seconds Displays: 4 Digits LED Display

Voltage Meter Accuracy:

Leakage Current Accuracy: ± 0.1 mA Full Scale

Duty Cycle: 100 % 15 - 40 °C Operation Temperature:

Relative Humidity Range: 0 - 90 % Non-Condensing



General

Dimensions: 17 in Wide x 6 in High x 17 in Deep

Weiaht:

Product Package: HT-10000P ac/dc

> HT-10000P ac/dc Product Manual 18 AWG Test Lead (Black)

18 AWG High Voltage Test Lead (Red) NIST Traceable Calibration Certificate to MIL-STD45662-A



Options

Two position terminal block on rear panel must be shorted for high voltage (XI) Safety Interlock:

operation.

If failure as Excess Leakage or Hipot Fail happens, it will terminate the test and (VF) Voltage on Failure:

the front voltage display will hold the last voltage reading.

(AR) Auto Reset on Pass: Resets the HT-10000P after a few seconds only on passing test condition. Voltage adjust knob must be to minimum position to allow start the test cycle. (ZOS) Zero Voltage Start: This option will bypass the Ramp Time Adjustment feature of the equipment. (RI) Relay Isolated Remote It allows the interface with a PLC or other machine using relay closures. This

Interface:

option allows isolation between the PLC and the Hipot tester.

Safety

Visual Indicator of Voltage

Provided by front panel meter, directly connected to high voltage output.

Output:

Failure Indicator: Audible, provided by buzzer. Visual, Provided by red LED's.

Test automatically terminated on failure.

Leakage Test: Provided, 1 mA AC factory set pass/fail point, user adjustable.

Distributed By:

Signal Test, Inc 1529 Santiago Ridge Way San Diego, CA 92154

Tel. 1-619-575-1577 USA www.SignalTestInc.com Sales@SignalTestInc.com

