

Hipot Testers

HT-10KVP ac 100mA

↘ FAST

↘ SAFE

↘ RELIABLE




↘ DIELECTRIC WITHSTAND

Model HT-10KVP ac 100mA is a 10,000V AC Hipot Tester

↘ Features

- AC output: up to 10,000 V.
- Microcontroller Technology, one button test, easy to setup, LED's indicate test progress. Upon failure, buzzer sounds and testing is terminated.
- Output voltage, leakage current limit and test duration are controlled from the front panel.
- Arc detection and test timer are defeatable.
- Separate arc detection circuitry.
- Main shutdown switch on front panel for safety.
- Safety Zero Voltage Start included.
- Ergonomically designed for safety, speed and efficiency.
- Designed for product development and laboratory use.
- Cables, manual and calibration certificate included.
- One year calibration cycle.
- One year warranty.



COMPLIANCE WEST USA
The blue box that tests. And tests.

HT-10KVP ac 100mA



FAST



SAFE



RELIABLE

Specifications

Voltage Test Type:	AC
Output Voltage:	0 - 1,000VAC
Leakage Current:	AC : 5 - 100mA
Input Voltage:	120V
Frequency:	50/60 Hz
Fuse:	10 A Slow Blow per phase
Breakdown Detect:	Independent High Frequency Circuit
Transformer Power:	> 500 VA
Leakage Current Detect:	Independent Low Frequency Circuit
Test Time Range:	1 - 90 Seconds
Displays:	4 Digits LED Display
Voltage Meter Accuracy:	± 0.1KV Full Scale (From 0.50KV to 10.00KV)
Leakage Current Accuracy:	± 1 mA Full Scale
Duty Cycle:	100 %
Operation Temperature:	15 - 40 °C
Relative Humidity Range:	0 - 90 % Non-Condensing

General

Dimensions:	17 in Wide x 11 in High x 17 in Deep
Weight:	80 lbs
Product Package:	HT-10KVP ac 100mA HT-10KVP ac 100mA Product Manual 18 AWG Test Lead (Black) Red High Voltage Heavy Duty Test (Red) NIST Traceable Calibration Certificate to MIL-STD45662-A

Options

(XI) Safety Interlock:	Two position terminal block on rear panel must be shorted for high voltage operation.
(VF) Voltage on Failure:	If failure as Excess Leakage or Hipot Fail happens, it will terminate the test and the front voltage display will hold the last voltage reading.
(AR) Auto Reset on Pass:	Resets the units after a few seconds only on passing test condition.
(RI) Relay Isolated Remote Interface:	It allows the interface with a PLC or other machine using relay closures. This option allows isolation between the PLC and the Hipot tester.

Safety

Visual Indicator of Voltage Output:	Provided by front panel meter, directly connected to high voltage output.
Failure Indicator:	Audible, provided by buzzer. Visual, Provided by red LED's. Test automatically terminated on failure.
Leakage Test:	Provided, 5 mA factory set pass/fail point, user adjustable.
Zero Voltage Start	Voltage adjust knob must be to minimum position to allow start the test cycle.

Distributed By:

Signal Test, Inc
1529 Santiago Ridge Way
San Diego, CA 92154

Tel. 1-619-575-1577 USA
www.SignalTestInc.com
Sales@SignalTestInc.com

SIGNAL TESTTM
New & Used Test Equipment